digital™

VAXstation 4000 Model 60 Optional Devices Service Information

EK-V4066-SV.001

Digital Equipment Corporation Maynard, Massachusetts First Edition, February 1992.

The information in this document is subject to change without notice and should not be construed as a commitment by Digital Equipment Corporation. Digital Equipment Corporation assumes no responsibility for any errors that may appear in this document.

The software described in this document is furnished under a license and may be used or copied only in accordance with the terms of such license.

No responsibility is assumed for the use or reliability of software on equipment that is not supplied by Digital Equipment Corporation or its affiliated companies.

Restricted Rights: Use, duplication, or disclosure by the U. S. Government is subject to restrictions as set forth in subparagraph ( c ) ( 1 ) ( ii ) of the Rights in Technical Data and Computer Software clause at DFARS 252.227–7013.

Copyright © by Digital Equipment Corporation 1992

All Rights Reserved. Printed in U.S.A.

The following are trademarks of Digital Equipment Corporation: DEC, DECstation, DEMPR, DIGITAL, MicroVAX, ULTRIX, VAX, VMS, and the DIGITAL logo.

This document was prepared using VAX DOCUMENT, Version 2.0.

# Contents

#### Preface

#### vii

#### **Mass Storage Devices** 1 1.1 RZ2x Hard Disk Drive ..... 1 - 2RZ2x Hard Disk Drive SCSI ID ..... 1.1.11 - 21.1.2RZ2x Hard Disk Drive Specifications ..... 1 - 51.2RRD42 CDROM Disc Drive 1 - 61.2.1RRD42 CDROM Disc Drive SCSI ID ..... 1 - 6RRD42 CDROM Disc Drive Specifications ..... 1.2.21 - 91.3RX26 Diskette Drive 1 - 101.3.1RX26 Diskette Drive SCSI ID ..... 1 - 101.3.2RX26 Diskette Drive Specifications ..... 1–12 1.4TZK10 (QIC) Tape Drive ..... 1–13 1.4.1TZK10 Tape Drive SCSI ID ..... 1–13 1.4.2TZK10 Tape Drive Specifications ..... 1–16

#### 2 Optional System Modules

2.1	MS44 Memory Module	2 - 2
2.1.1	MS44 Memory Module Specifications	2-4
2.2	DSW21 Synchronous Communications Adapter	2 - 5
2.2.1	DSW21 Synchronous Communications Adapter Cables	2 - 7
2.2.2	Installing the DSW21 Adapter	2 - 7
2.2.3	DSW21 Environmental Specifications	2 - 8
2.2.4	DSW21 Physical Specifications	2–9

iv Contents

# 3 Optional System Monitors

3.1	VR319 Monochrome Monitor	3 - 2
3.1.1	Refresh Rate	3–3
3.1.2	VR319 Monochrome Monitor Specifications	3–5
3.1.2.	1 VR319 Monochrome Monitor Video Timing	3–6
3.2	VR320 Color Monitor	3 - 7
3.2.1	Refresh Rate	3–8
3.2.2	VR320 Color Monitor Specifications	3 - 10
3.2.2.	1 VR320 Color Monitor Video Timing	3 - 11
3.3	VR262 Monochrome Monitor	3 - 12
3.3.1	VR262 Monochrome Monitor Specifications	3 - 12
3.4	VR299 Color Monitor	3 - 14
3.4.1	VR299 Color Monitor Specifications	3 - 14
3.5	VRT16 Color Monitor	3 - 15
3.5.1	VRT16 Color Monitor Specifications	3 - 15
3.6	VRT19 Color Monitor	3–16
3.6.1	VRT19 Color Monitor Specifications	3–16

# 4 Optional System Printers

LA75 Companion Printer	4 - 2
LA75 Companion Printer Configuration	4–4
LA75 Companion Printer Specifications	4 - 5
LA210 Letterprinter	4–6
LA210 Letterprinter Configuration	4–9
LA210 Letterprinter Specifications	4–11
LN03 Laser Printer	4 - 12
LN03 Laser Printer Configuration	4 - 13
LN03 Laser Printer Specifications	4 - 15
	LA75 Companion PrinterLA75 Companion Printer ConfigurationLA75 Companion Printer SpecificationsLA210 LetterprinterLA210 Letterprinter ConfigurationLA210 Letterprinter SpecificationsLN03 Laser PrinterLN03 Laser Printer ConfigurationLN03 Laser Printer SpecificationsLN03 Laser Printer Specifications

# Index

#### Contents v

# Figures

1–1	RZ23L SCSI ID Jumper Location	1 - 3
1 - 2	RRD42 CDROM Disc Drive Jumper Location	1 - 7
1 - 3	RX26 Diskette Drive SCSI ID Switch Location	1–11
1 - 4	Verifying the TZK10 Tape Drive SCSI ID	1 - 14
2 - 1	MS44 Memory Module	2 - 3
2 - 2	DSW21 Synchronous Communications Adapter	2 - 5
2 - 3	DSW21 Synchronous Communications Adapter	2-6
3 - 1	VR319 Monochrome Monitor	3 - 2
3 - 2	Refresh Rate Jumper—Deflection Module	3–3
3–3	Refresh Rate Jumper—Power Supply Module	3–4
3–4	VR320 Color Monitor	3 - 7
3-5	Refresh Rate Switch—Deflection Module	3–8
3–6	Refresh Rate Jumper—Power Supply Module	3–9
4–1	LA75 Companion Printer	4–3
4 - 2	LA210 Letterprinter	4–6
4–3	RS232C Serial Interface Connector	4 - 7
4–4	Parallel Interface Switches (Optional)	4–8
4 - 5	LA210 Letterprinter Configuration Switches	4–10
4–6	LN03 Laser Printer	4–12
4–7	LN03 Laser Printer Configuration Switches	4–14

#### Tables

1–1	Capacities of RZ23L, RZ24, and RZ25 Drives	1 - 2
1 - 2	RZ23L/RZ24 SCSI Jumper Settings	1–4
1 - 3	RZ25 SCSI Jumper Settings	1–4
1–4	RZ23L Disk Drive Operating Environment	1 - 5
1 - 5	RZ23L Disk Drive Physical Dimensions	1 - 5
1–6	RZ24 Disk Drive Operating Environment	1 - 5
1 - 7	RZ24 Disk Drive Physical Dimensions	1–6
1–8	RRD42 CDROM Disc Drive Jumper Settings	1–8
1–9	RRD42 Disc Drive Operating Environment	1–9
1 - 10	RX26 Diskette SCSI ID Switch Setting	1–11
1–11	RX26 Environmental Specifications	1 - 12
1 - 12	Diskette and Format Information	1 - 12

1 - 13	TZK10 Tape Drive SCSI Jumper Settings	1 - 15
1 - 14	TZK10 Cartridge Tape Drive Dimensions	1 - 16
1 - 15	TZK10 Cartridge Tape Drive Operating Environment	1 - 16
2 - 1	DSW21 Adapter Cables	2-7
2 - 2	DSW21 Environmental Specifications	2 - 8
2 - 3	Physical Specifications	2–9
4–1	LA75 Factory Set Configurations	4–4

# Preface

This manual is a support and reference document for Digital Services personnel who perform maintenance on the VAXstation 4000 Model 60 workstation. It is also intended for Digital customers who have a self-maintenance agreement with Digital.

# **Organization of This Manual**

This manual contains the following chapters:

- Chapter 1 describes the optional mass storage devices that can be configured with the system, and explains how to install the devices.
- Chapter 2 describes the optional system modules that can be configured with the system. Installation procedures for each module are also in this chapter.
- Chapter 3 describes the optional monitors that can be configured with the system.
- Chapter 4 describes the optional printers that can be configured with the system.

# **Associated Documentation**

The following documents provide additional information about the VAXstation 4000 Model 60 workstation:

Document	Part Number
VAXstation 4000 Model 60 Documentation Kit	EK-V4666-DK
VAXstation 4000 Model 60 Service Information	EK-V466B-SV
VAXstation 4000 Model 60 Pocket Service Information	EK-V466H-PS
VAXstation 4000 Model 60 Quick Installation Card	EK-PMARI-IN

viii Preface

Document	Part Number	
VAXstation 4000 Model 60 Owner's and System Installation Guide	EK-PMARI-OM	
VAXstation 4000 Model 60 Options Installation Guide	EK-PVAX2-IG	
VAXstation 4000 Model VLC Service Information	EK-V48VB-SV	
BA46 Storage Expansion Box Owner's Guide	EK-STEXP-IG	
BA46 Storage Expansion Box Maintenance Guide	EK-VBA46-SV	
BA42 Storage Expansion Box Maintenance Guide	EK-BA42A-MG	

# Conventions

The following conventions are used in this guide.

Convention	Description
WARNING	Contains important information that relate to personal safety.
CAUTION	Contains information to prevent damage to the equipment.
NOTE	Contains general information.
PN	Part number

# **1** Mass Storage Devices

This chapter describes the optional mass storage devices that can be configured in the VAXstation 4000 Model 60 system unit. The devices are:

Section 1.1	RZ23L, RZ24, and RZ25 Hard Disk Drives
Section 1.2	RRD42 Compact Disc Drive
Section 1.3	RX26 Diskette Drive
Section 1.4	TZK10 Tape Drive

NOTE

The system unit can hold one device from which the storage medium is removable, such as the RRD42, RX26, or TZK10 drives. To add more than one removable media device, you need an expansion box. 1-2 Mass Storage Devices

### 1.1 RZ2x Hard Disk Drive

The RZ23L, RZ24, and RZ25 hard disk drives provide memory storage for applications and user files. The RZ2x drives store information on a non-removable disk. Table 1–1 lists the storage capacities for the RZ2x drives.

Table 1–1 Capacities of RZ23L, RZ24, and RZ25 Drives

Drive	Capacity	
RZ23L	121 MB	
RZ24	209 MB	
RZ25	426 MB	

#### 1.1.1 RZ2x Hard Disk Drive SCSI ID

Before you install the RZ23L, RZ24, or RZ25 drive in the system, you need to verify the SCSI ID setting as follows:

- 1. Turn the RZ23L, RZ24, or RZ25 drive so that the bottom of the drive is facing you. Find the SCSI ID jumpers, which are removable electrical connectors, that allow you to select a unique ID number for each SCSI device:
  - If you have an RZ23L or RZ24 drive, find jumpers E1, E2, and E3.
  - If you have an RZ25 drive, find jumpers P1, P2, and P3.

#### NOTE

If your hard disk drive was not factory installed, it could have been shipped with all the jumpers attached (to prevent loss of jumpers when shipping and unpacking). In this case, the SCSI ID is set to 7, and you may need to change it.

2. Verify that the jumpers are set to the appropriate positions for SCSI ID 0, 1, or 2. These are the positions that the RZ2x drive normally uses. If you have one RZ23L, RZ24, or RZ25 drive that was factory installed, verify that the jumpers are set for SCSI ID 3. If you have two RZ23L, RZ24, or RZ25 drives that were factory installed, verify that the jumpers on one of them are set for SCSI ID 3, and that the jumpers on the other are set to either SCSI ID 0, 1, or 2. Any RZ2x drive can be set to SCSI ID 0, 1, 2, or 3, if no other drive uses that ID. See Table 1–2 (for RZ23L and RZ24 drives) or Table 1–3 (for RZ25 drives) for the correct jumper positions for each of these SCSI IDs.

Mass Storage Devices 1–3

NOTE

Settings should be changed only when a system is configured with more than one of a particular device. You are responsible for the SCSI ID settings on your equipment.

If you are adding an RZ23L, RZ24, or RZ25 drive, the SCSI ID could need changing. Drives not factory installed could have all jumpers in place (set for position 7) to prevent misplacing the jumpers during shipping and unpacking.

Figure 1–1 shows the location of the RZ2x drive SCSI ID jumpers.





#### 1-4 Mass Storage Devices

	Recommended	<b>Jumper Positions</b>			
Device	SCSI ID	<b>E</b> 1	E2	<b>E3</b>	
RZ23L/RZ24/RZ25	0	$\operatorname{Out}^1$	Out	Out	
RZ23L/RZ24/RZ25	1	$\mathrm{In}^1$	Out	Out	
RZ23L/RZ24/RZ25	2	Out	In	Out	
RZ23L/RZ24/RZ25 (factory-installed)	3	In	In	Out	
RRD42	4	Out	Out	In	
RX26/TZK10	5	In	Out	In	
SCSI controller	6	Out	In	In	
High-priority device	7	In	In	In	

#### Table 1–2 RZ23L/RZ24 SCSI Jumper Settings

#### Table 1–3 RZ25 SCSI Jumper Settings

	Recommended	<b>Jumper Positions</b>		
Device	SCSI ID	<b>P1</b>	<b>P2</b>	<b>P3</b>
RZ23L/RZ24/RZ25	0	$\operatorname{Out}^1$	Out	Out
RZ23L/RZ24/RZ25	1	Out	Out	$\mathrm{In}^1$
RZ23L/RZ24/RZ25	2	Out	In	Out
RZ23L/RZ24/RZ25 (factory-installed)	3	Out	In	In
RRD42	4	In	Out	Out
RX26/TZK10	5	In	Out	In
SCSI controller	6	In	In	Out
High-priority device	7	In	In	In
$^{1}$ Out = Removed; In = atta	ched			

For information on installing the RZ2x disk drives, refer to the VAXstation 4000 Model 60 Options Installation Guide (PN EK-PVAX2-IG).

Mass Storage Devices 1-5

#### 1.1.2 RZ2x Hard Disk Drive Specifications

Table 1–4 and Table 1–5 list the specifications for the RZ23L hard disk drive. Table 1–6 and Table 1–7 list the specifications for the RZ24 hard disk drive.

Table 1–4 RZ23L Disk Drive Operating Environment

Temperature range	10° C to 60° C (50° F to 110° F)
Relative humidity	8% to 80%
Altitude	-304 m to 3048 m (-1000 ft to 10,000 ft)
Maximum wet bulb temperature	25.6° C (78° F)
Heat dissipation	8 W (typical) (27.36 Btu/hr) 9 W max. (30.8 Btu/hr)
Temperature gradient	11° C/hr (20° F/hr)

Table 1–5	RZ23L	Disk	Drive	Physical	Dimensions
-----------	-------	------	-------	----------	------------

Height	Width	Depth	Weight
41.28 mm	101.6 mm	146.05 mm	.826 kg
(1.625 in)	(4.00 in)	(5.75 in)	(1.82 lbs)

#### Table 1–6 RZ24 Disk Drive Operating Environment

Temperature range	10° C to 55° C (50° F to 99° F)
Relative humidity	8% to 80%
Altitude	-304 m to 4573 m (-1000 ft to 15,000 ft)
Maximum wet bulb temperature	25.6° C (78° F)
Heat dissipation	6.6 W (seeking) (22.57 Btu/hr) 6.8 W (read/write mode) (23.26 Btu/hr)
Temperature gradient	11° C/hr (20° F/hr)

1-6 Mass Storage Devices

Height	Width	Depth	Weight	
41.28 mm	101.6 mm	146.05 mm	.780 kg	
(1.625 in)	(4.00 in)	(5.75 in)	(1.72 lbs)	

### 1.2 RRD42 CDROM Disc Drive

The RRD42 CDROM compact disc drive is a storage device that reads data from removable compact discs. The drive has a storage capacity of 600 Mbytes. The RRD42 drive can be used to install the VMS operating system and other software, and to access read-only databases, such as online documentation sets. The drive has audio output capabilities, allowing the use of headphones for listening to audio information recorded on the compact disc.

#### 1.2.1 RRD42 CDROM Disc Drive SCSI ID

Before installing the RRD42 drive, verify the SCSI ID on the drive as follows:

- 1. Turn the RRD42 drive so that the rear of the drive is facing you. Find SCSI ID jumpers 0, 1, and 2, on the rear of the drive, as shown in Figure 1–2. Jumpers are removable electrical connectors that allow you to select a unique ID number for each SCSI device.
- 2. Verify that the jumpers are set as follows:

Jumper 0 = Out (removed) Jumper 1 = Out (removed) Jumper 2 = In (attached)

These are the positions for SCSI ID 4, which is the default SCSI ID for the drive.

Mass Storage Devices 1-7

0000 000 l٥ 0000 000 0 ۱. I L \_ 5V±5% GND 12V±10% R GND DC INPUT AUDIO OUT 0 1 2 MODE -ID SELECT <u>:::</u> [0000] F -FRAME SCSI BUS GROUND POWER-IN INTERFACE TAB CONNECTOR CONNECTOR SHR-XR0064-90

Figure 1–2 RRD42 CDROM Disc Drive Jumper Location

#### NOTE

#### Default settings should be changed only when a system is configured with more than one of a particular device. You are responsible for the SCSI ID settings on your equipment.

If you want to use a different ID, choose a new ID from Table 1–8, and carefully remove or replace jumpers accordingly, using tweezers or another small tool.

#### NOTE

Save any SCSI jumpers you remove for later use, if necessary.

#### CAUTION

Never set two devices to the same SCSI ID; the system cannot communicate with devices set to the same ID.

#### 1-8 Mass Storage Devices

Table 1–8 lists the jumper settings for the RRD42 disc drive.

	Recommended	<b>Jumper Positions</b>			
Device	SCSI ID	0	1	2	
RZ23L/RZ24/RZ25	0	$\operatorname{Out}^1$	Out	Out	
RZ23L/RZ24/RZ25	1	$\mathrm{In}^1$	Out	Out	
RZ23L/RZ24/RZ25	2	Out	In	Out	
Factory-installed RZ23L/RZ24/RZ25	3	In	In	Out	
RRD42	4	Out	Out	In	
RX26/TZK10	5	In	Out	In	
SCSI controller	6	Out	In	In	
High-priority device	7	In	In	In	

Table 1–8 RRD42 CDROM Disc Drive Jumper Settings

To install the RRD42 drive, refer to the VAXstation 4000 Model 60 Options Installation Guide (PN EK-PMARI-IG).

Mass Storage Devices 1-9

#### 1.2.2 RRD42 CDROM Disc Drive Specifications

Table 1–9 lists the operating environment for RRD42 disc drive.

	· · · · · · · · · · · · · · · · · · ·
Temperature range	5° C to 50° C (41° F to 122° F)
Relative humidity	10% to 90%, non-condensing
Altitude	2400 m (8000 ft) at 36° C (96° F)
Maximum wet bulb temperature	29° C (84° F)

#### Table 1–9 RRD42 Disc Drive Operating Environment

NOTE

Be sure the "Mode" jumper is in. This jumper must be in place to use the drive with the VMS operating system.

CAUTION

Each device must have a unique SCSI ID. Never set two devices to the same SCSI ID; the system cannot communicate with devices set to the same ID.

1–10 Mass Storage Devices

### 1.3 RX26 Diskette Drive

The RX26 is a half-height diskette drive that can be used for selective file backup, load applications, and transporting files between non-networked systems. The RX26 drive has a storage capacity of 4 Mbytes. It can be used to read and write on 4 Mbyte standard floppies, and to read only 700 KB standard floppies.

#### 1.3.1 RX26 Diskette Drive SCSI ID

Before installing the RX26 drive in the system, verify the SCSI ID setting.

- 1. Turn the RX26 drive so that the left side of the drive is facing you. Find the SCSI ID switches 1, 2, and 3 on the drive, as shown in Figure 1–3.
- 2. Use a pen or small pointed object to move the switches up or down.

#### CAUTION

# Do not use a pencil to move switches. Graphite particles can damage the SCSI switches.

Digital recommends that the SCSI ID switches be set to 5 as follows:

Switch 1 = Down (on) Switch 2 = Up (off) Switch 3 = Down (on)

#### NOTE

#### Default settings should be changed only when a system is configured with more than one of a particular device. You are responsible for the SCSI ID settings on your equipment.

If you need to use a different ID, choose a new ID from Table 1–10. Use a small pointed instrument (but **not** a pencil), set the switches accordingly.

#### CAUTION

# Never set two devices to the same SCSI ID; the system cannot communicate with devices set to the same ID.

To install the RX26 drive, refer to the VAXstation 4000 Model 60 Options Installation Guide (PN EK-PMARI-IG).

Mass Storage Devices 1-11

# Switches Positions: Up (Off) Down (On) 1 2 3 1 2 3

#### Figure 1–3 RX26 Diskette Drive SCSI ID Switch Location

DeviceSCSI ID210RZ23L/RZ24/RZ250UpUpUpUpRZ23L/RZ24/RZ251DownUpUpRZ23L/RZ24/RZ252UpDownUpFactory-installed RZ23L/RZ24/RZ253DownDownUpRRD424UpUpDownRX26/TZK105DownUpDownSCSI controller6UpDownDown(High-priority device)7DownDownDown		Recommended	Switch Positions			
RZ23L/RZ24/RZ250UpUpUpRZ23L/RZ24/RZ251DownUpUpRZ23L/RZ24/RZ252UpDownUpFactory-installed RZ23L/RZ24/RZ253DownDownUpRRD424UpUpDownRX26/TZK105DownUpDownSCSI controller6UpDownDown(High-priority device)7DownDownDown	Device	SCSI ID	2	1	0	
RZ23L/RZ24/RZ251DownUpUpRZ23L/RZ24/RZ252UpDownUpFactory-installed RZ23L/RZ24/RZ253DownDownUpRRD424UpUpDownDownRX26/TZK105DownUpDownDownSCSI controller6UpDownDownDown(High-priority device)7DownDownDownDown	RZ23L/RZ24/RZ25	0	Up	Up	Up	
RZ23L/RZ24/RZ252UpDownUpFactory-installed RZ23L/RZ24/RZ253DownDownUpRRD424UpUpDownDownRX26/TZK105DownUpDownDownSCSI controller6UpDownDownDown(High-priority device)7DownDownDownDown	RZ23L/RZ24/RZ25	1	Down	Up	Up	
Factory-installed RZ233L/RZ24/RZ253DownDownUpRRD424UpUpDownRX26/TZK105DownUpDownSCSI controller6UpDownDown(High-priority device)7DownDownDown	RZ23L/RZ24/RZ25	2	Up	Down	Up	
RRD424UpUpDownRX26/TZK105DownUpDownSCSI controller6UpDownDown(High-priority device)7DownDownDown	Factory-installed RZ23L/RZ24/RZ25	3	Down	Down	Up	
RX26/TZK105DownUpDownSCSI controller6UpDownDown(High-priority device)7DownDownDown	RRD42	4	Up	Up	Down	
SCSI controller6UpDownDown(High-priority device)7DownDownDown	<b>RX26</b> /TZK10	5	Down	Up	Down	
(High-priority device) 7 Down Down Down	SCSI controller	6	Up	Down	Down	
	(High-priority device)	7	Down	Down	Down	

1–12 Mass Storage Devices

# 1.3.2 RX26 Diskette Drive Specifications

5° C to 50° C (40° F to 122° F)
-20° C to 66° C (-4° F to 151° F)
8% to $80%,$ wet bulb @ 25.6° C (78.0° F), no condensation
5% to 95%, wet bulb @ 46° C (115.0° F), no condensation
-304 m to 3,048 m (-1000 ft to 10,000 ft)
-304 m to 12,192 m (-1000 ft to 40,000 ft)

 Table 1–11
 RX26 Environmental Specifications

Table 1–12	Diskette	and	Format	Information
------------	----------	-----	--------	-------------

Number of cylinders	80
Number of tracks	160
Number of read/write heads	2

Mass Storage Devices 1-13

# 1.4 TZK10 (QIC) Tape Drive

The TZK10 tape drive is a half-height device that uses industry standard quarter-inch cartridge (QIC) tapes for loading applications and doing file backups. The formatted capacity of the QIC tape is 320 Mbytes or 525 Mbytes, depending on the tape used.

#### 1.4.1 TZK10 Tape Drive SCSI ID

Before installing the TZK10 drive, verify the SCSI ID on the drive as follows:

- 1. Turn the TZK10 drive so that the rear of the drive is facing you. Find SCSI ID jumpers 0, 1, and 2. Jumpers are removable electrical connectors that allow you to select a distinct ID for each SCSI device.
- 2. Verify that the jumpers are set as follows:

Jumper 0 = In (attached) Jumper 1 = Out (removed) Jumper 2 = In (attached)

These are the positions for SCSI ID 5, which is the setting that the TZK10 drive normally uses.

#### NOTE

Default settings should be changed only when a system is configured with more than one of a particular device. You are responsible for the SCSI ID settings on your equipment. 1–14 Mass Storage Devices

Figure 1–4 Verifying the TZK10 Tape Drive SCSI ID



Mass Storage Devices 1-15

If you want to use a different ID, choose a new ID from Table 1-13 and carefully remove or replace jumpers accordingly. Use tweezers or another small tool to remove or replace jumpers.

#### NOTE Save any SCSI jumpers you remove for later use, if necessary.

	-			
	Recommended	J	Jumper Positions	
Device	SCSI ID	2	1	0
RZ23L/RZ24/RZ25	0	Out	Out	Out
RZ23L/RZ24/RZ25	1	Out	Out	In
RZ23L/RZ24/RZ25	2	Out	In	Out
Factory-installed RZ23L/RZ24/RZ25	3	Out	In	In
RRD42	4	In	Out	Out
RX26/ <b>TZK10</b>	5	In	Out	In
SCSI controller	6	In	In	Out
High-priority device	7	In	In	In

Table 1–13 TZK10 Tape Drive SCSI Jumper Settings

#### NOTE

Be sure the "Mode Select" jumper is in. This jumper must be in place to use the drive with the VMS operating system.

#### CAUTION

Each device must have a unique SCSI ID. Never set two devices to the same SCSI ID; the system cannot communicate with devices set to the same ID.

For information on installing the TZK10 (QIC) tape drives, refer to the VAXstation 4000 Model 60 Options Installation Guide (PN EK-PVAX2-IG).

1–16 Mass Storage Devices

# 1.4.2 TZK10 Tape Drive Specifications

Table 1–14 TZK10 Cartridge Tape Drive Dimensions

Height	Width	Depth	Weight
4.4 cm	14.6 cm	20.8 cm	1.1 kg
(1.7 in)	(5.25 in)	(8.2 in)	(2.4 lbs)

|--|

Temperature range	$5^\circ$ C to $40^\circ$ C (41° F to 122° F)
Relative humidity	10% to 90%, non-condensing
Altitude	0 m to 2400 m (0 ft to 13,000 ft)
Maximum wet bulb temperature	26° C (79° F)
Minimum dew point	2° C (36° F)

# **2** Optional System Modules

This chapter describes the optional modules that can be installed in the VAXstation 4000 Model 60 system. The optional modules are:

Section 2.1	MS44 Memory Module
Section 2.2	DSW21 Synchronous Communications Adapter

2-2 Optional System Modules

#### 2.1 MS44 Memory Module

The MS44 memory module is designed to provide expandable memory for the VAXstation 4000 Model 60 system. The memory array consists of 36 DRAMs organized as one bank of four- to nine-bit bytes. Timing and addressing of the array are provided by the system module and are buffered on the memory module. Data lines are unbuffered on the module and are driven on bi-directional lines to and from the DRAMs. All data and control lines receive one unit load per module.

Three types of memory module are available: 4 Mbyte (MS44-AA), 4 Mbyte Reduced Cost (MS44-AL), and 16 Mbyte (MS44-CA). The VAXstation 4000 Model 60 can use any of the three memory modules. Memory modules must be installed in pairs; two 4 Mbyte modules for two 16 Mbyte modules.

To identify a memory module, locate the etch on the left side of the memory module. The 4 Mbyte modules have AA or AL on the etch board, and the 16 Mbyte modules have CA on the etch board. The memory modules are shown in Figure 2-1.

When the module pairs are configured together, the MS44-AA module pairs should be installed in the lower numbered areas. The maximum system memory configuration is 104 Mbytes for the Model 60.

For additional information on installing memory modules, refer to the VAXstation 4000 Model 60 Service Information (PN EK-V466B-SV).

Optional System Modules 2-3





LJ-00499-TI0

2-4 Optional System Modules

#### 2.1.1 MS44 Memory Module Specifications

The MS44 memory module specifications are listed next.

#### **Total Memory Power Required**

Total DRAM Current	$2.45 \mathrm{A}$
Total Driver Current	0.10 A
Total Current	$2.55~\mathrm{A}$
Total Active Power	13.38 W
Total Standby Power	$1.25 \mathrm{~W}$

#### **Total System Requirements**

Total Memory	Current	5.69 A	
Total Memory	Power	29.86 W	I

NOTE

The current specifications for the memory modules assume 24 Mbytes and QUADWORD operations with 2 memory modules active and 4 memory modules in standby. Optional System Modules 2-5

# 2.2 DSW21 Synchronous Communications Adapter

The DSW21 adapter is a synchronous serial communications interface for the VAXstation 4000 Model 60 workstation. It has full modem control and multiple protocol support. Figure 2–2 shows the DSW21 communications adapter.

#### Figure 2–2 DSW21 Synchronous Communications Adapter



The DSW21 adapter is an option board that connects internally to the CPU board via a 64-pin option connector. It consists of the EDAL interface, 128 KB UVEPROM, 256 KB Static RAM, the MC68302 Integrated Multi-Protocol Processor (IMP), and I/O receivers and drivers with static and lightning protection. The communications I/O connector is a 50-pin D-subminiature plug that goes directly through the back of the system cabinet. Figure 2–3 shows the DSW21 connections.



Figure 2–3 DSW21 Synchronous Communications Adapter



LJ-01668-GRA

Optional System Modules 2-7

#### 2.2.1 DSW21 Synchronous Communications Adapter Cables

Adapter cables for the DSW21 communications adapter vary according to the option ordered. The following table lists the adapter cable variations.

Table 2–1 DSW21 Adapter Cables

DSW21 Model	Adapter Cables
DSW21-AA	1 line sync comm, BC19V EIA-232/V.24
DSW21-AB	1 line sync comm, BC19W EIA-449/423/V.10
DSW21-AC	1 line sync comm, BC19U EIA-449/422/V.36
DSW21-AD	1 line sync comm, BC19X V.35
DSW21-AE	1 line sync comm, BC19Q EIA-530
DSW21-AF	1 line sync comm, BC20Q X.21
DSW21-M	1 line sync comm controller, no adapter cable
DSW21-AF DSW21-M	<ol> <li>line sync comm, BC20Q X.21</li> <li>line sync comm controller, no adapter cable</li> </ol>

#### 2.2.2 Installing the DSW21 Adapter

This section describes how to install the DSW21 interface in the system unit.

#### NOTE

# Refer to the system preparation instructions in the VAXstation 4000 Model 60 Service Information before installing any module in the workstation.

To install the communications interface, do the following:

- 1. Remove any rear panels or shields (if applicable) from the I/O panel.
- 2. Mount the DSW21 internally to the Model 60 via the 64-pin option connector. There are no clips or screws to hold the option connector.
- 3. Attach the 50-pin data connector, which protrudes through the rear of the enclosure and is held in place by the metal bracket.
- 4. Restore the system. Test the new configuration.

2-8 Optional System Modules

# 2.2.3 DSW21 Environmental Specifications

The DSW21 module assembly meets Digital Standard 102 class C environmental specifications.

Parameter	Range
Operating temperature	5°C to 50° C (41°F to 122 °F)
Nonoperating temperature	-40°C to 66° C (-40°F to 155°F)
Relative humidity (operating)	10% to $95%$ (noncondensing)
Relative humidity (nonoperating)	10% to 95%
Maximum wet bulb temperature (operating)	32 °C (90°F)
Maximum wet bulb temperature (nonoperating)	46 °C (115°F)
Minimum dew point temperature (operating)	2 °C (36°F)
Head dissipation	6.75 watts to 8.10 watts Btu/h
Altitude (operating)	2400 m (8000 ft)
Altitude (nonoperating)	4900 m (16000 ft)

Table 2–2 DSW21 Environmental Specifications

#### NOTE

De-rate the maximum operating temperature by 1.82 degrees Celsius for each 1000 meters of altitude above sea level. Reference: Standard Atmosphere, Standard Gravity.

This device is to operate in a non-caustic environment.

Optional System Modules 2-9

# 2.2.4 DSW21 Physical Specifications

The DSW21 adapter is a four layer circuit board assembly with the following specifications.

Table 2–3 Physical Specifications

Parameter	Range
Height	4.3 cm (1.7 in)
Width	12.4 cm (4.9 in)
Depth	14 cm (5.5 in)
Weight	.45 kg (1 lb)

# **3** Optional System Monitors

This chapter describes the optional monitors that can be connected externally to the VAXstation 4000 Model 60 system. The monitors are:

Section 3.1	VR319 Monochrome Monitor
Section 3.2	VR320 Color Monitor
Section 3.3	VR262 Monochrome Monitor
Section 3.4	VR299 Color Monitor
Section 3.5	VRT16 Color Monitor
Section 3.6	VRT19 Color Monitor

3-2 Optional System Monitors

# 3.1 VR319 Monochrome Monitor

The VR319 monochrome monitor (Figure 3–1) has a 500 mm (20 in), direct-viewed, anti-glare CRT. The built-in tilt/swivel assembly allows you to adjust the screen for viewing.





Optional System Monitors 3-3

#### 3.1.1 Refresh Rate

The VR319 monochrome monitor operates at either a 66 Hz or 72 Hz refresh rate. The refresh rate is preset for the system before the monitor is shipped. If you change the monitor to another system, check the refresh rate of the new system and then set the jumpers on the deflection module (Figure 3–2) and power supply module (Figure 3–3) to match the new system. For additional information, refer to the VR319 Monitor Service Guide (PN EK-VR319-SV).









Figure 3–3 Refresh Rate Jumper—Power Supply Module

Optional System Monitors 3-5

# 3.1.2 VR319 Monochrome Monitor Specifications

The VR319 monochrome monitor specifications are listed next.

#### **Power Requirements**

	Voltage	88 to 132 Vac or 176 to 264 Vac auto-ranging, single phase, 3-wire
	Frequency	47 to 63 Hz
	Power Consumption	135 W maximum
Operatin	g Environment	
	Temperature Range	$10^\circ$ C to $40^\circ$ C (50° F to $104^\circ$ F)
	Relative humidity	10% to 95% Maximum wet bulb = 32° C Minimum dew point = 2°C (noncondensing)
Physical	Characteristics	
	Height	45.7 cm (18.0 in)
	Width	49.5 cm (19.5 in)
	Depth	40.1 cm (15.8 in)
	Weight	22 kg (48.0 lb)
	Tilt Range	-5° forward to +15° backward
	Swivel Range	±90° (left and right)
	Display - Cathode ray tube (CRT)	48.3 cm (19 in) diagonal
	Display area	1280 pixels horizontal x 1024 lines vertical.
		Approximate picture size: 34.3 cm (13.5 in) x 27.3 cm (10.75 in) with a 5:4 aspect ratio.
	Light transmission	42% nominal
	Video input	Composite video

#### 3-6 Optional System Monitors

#### 3.1.2.1 VR319 Monochrome Monitor Video Timing

The VR319 monochrome monitor video timing is listed in the following tables.

#### Video Timing-1280 x 1024 Resolution

	Refre	esh Rate
	72 Hz	66 Hz
Horizontal frequency	77.17 kHz	70.66 kHz
Vertical frequency	$72.55~\mathrm{Hz}$	66.47 Hz
Pixel frequency	130.81 MHz	119.84 MHz
Pixel period	7.64 ns	8.34 ns

Horizontal timing	No. Pixels	μs	μs
Entire line	1696	12.96	14.15
Active visible line	1280	9.79	10.68
Blanking interval	416	3.18	3.47
Sync front porch	32	0.24	0.27
Sync pulse	160	1.22	1.34
Sync back porch	224	1.71	1.87

Vertical timing	No. Lines	ms	ms
Vertical period (Entire Frame)	1063	13.78	15.04
Visible raster	1024	13.28	15.04
Blanking interval	39	0.506	0.552
Sync front porch	3	0.039	0.042
Sync pulse	3	0.039	0.042
Sync back porch	33	0.428	0.467

Optional System Monitors 3-7

# 3.2 VR320 Color Monitor

The VR320 color monitor (Figure 3–4) has a direct-viewed, 485 mm (19 in), anti-glare CRT with contrast enhancement. The monitor has a built-in tilt and swivel assembly, allowing you to adjust the screen for viewing.

Figure 3–4 VR320 Color Monitor



3-8 Optional System Monitors

#### 3.2.1 Refresh Rate

The VR320 color monitor operates at a refresh rate of either 66 Hz or 72 Hz. The refresh rate is preset for the system before the monitor is shipped. If you change the monitor to another system, check the refresh rate of the new system and then set the switch on the deflection module (Figure 3–5) and the jumpers on the power supply module (Figure 3–6) to match the new system. For additional information, refer to the VR320 Monitor Service Guide (PN EK-VR320-SV).

#### Figure 3–5 Refresh Rate Switch—Deflection Module



LJ-00525-T10

Optional System Monitors 3-9



Figure 3–6 Refresh Rate Jumper—Power Supply Module

3–10 Optional System Monitors

# 3.2.2 VR320 Color Monitor Specifications

The VR320 color monitor specifications are listed next.

#### **Power Requirements**

	Voltage	88 to 132 Vac or 176 to 264 Vac auto-ranging, single phase, 3-wire
	Frequency	47 to 63 Hz 47 to 63 Hz
	Power consumption	220 W maximum
Operatir	ng Environment	
	Temperature range	10° C to 40° C (50° F to 104° F)
	Relative humidity	10% to 95% Maximum wet bulb = 32° C Minimum dew point = 2°C (noncondensing)
Physical	Characteristics	
	Height	45.7 cm (18.0 in)
	Width	49.5 cm (19.5 in)
	Depth	45.2 cm (17.8 in)
	Weight	29.0 kg (63.0 lb)
	Tilt range	-5° forward to +15° backward
	Swivel range	±90° (left and right)
	Display - Cathode ray tube (CRT)	48.3 cm (19.0 in) diagonal
	Display area	1280 pixels horizontal x 1024 lines vertical
		Approximate picture size: $34.3 \text{ cm}$ (13.5 in) x 27.3 cm (10.75 in) with a 5:4 aspect ratio.
	Light transmission	58% nominal
	Video input	Red (with sync) 1 Vpp, 75 ohm, ac or dc coupled $% \left( {{\left( {{{\rm{A}}} \right)}_{\rm{A}}} \right)_{\rm{A}}} \right)$
		Green (with sync) 1 Vpp, 75 ohm, ac or dc coupled
		Blue (with sync) 1 Vpp, 75 ohm, ac or dc coupled

Optional System Monitors 3-11

#### 3.2.2.1 VR320 Color Monitor Video Timing

The VR320 color monitor video timing is listed in the following tables.

#### Video Timing-1280 x 1024 Resolution

Refresh Rate			
	72 Hz	66 Hz	
Horizontal frequency	77.13 kHz	70.66 kHz	
Vertical frequency	72.56 Hz	66.47 Hz	
Pixel frequency	130.81 MHz	119.84 MHz	
Pixel period	7.64 ns	8.34 ns	

Horizontal Timing	No. Pixels	μs	μs
Entire line	1696	12.97	14.15
Active visible line	1280	9.79	10.68
Blanking interval	416	3.18	3.47
Sync front porch	32	0.245	0.267
Sync pulse	160	1.22	1.34
Sync back porch	224	1.71	1.87

Vertical Timing	No. Lines	ms	ms
Vertical period (Entire Frame)	1063	13.78	15.04
Visible raster	1024	13.28	14.49
Blanking interval	39	0.506	0.552
Sync front porch	3	0.03889	0.04246
Sync pulse	3	0.03889	0.04246
Sync back porch	33	0.4279	0.4670

3-12 Optional System Monitors

# 3.3 VR262 Monochrome Monitor

The VR262 monochrome monitor is compatible with the VR260 monitor. The VR262 monitor has a direct-viewed, 485 mm (19 in) diagonal antiglare screen with contrast enhancement. When connected to a host system, the VR262 monitor can display information sent to the host and information that the host system sends to you.

For installation and troubleshooting information, refer to *Installing and* Using the VR262 Monochrome Monitor (PN EK-VR262-IN).

#### 3.3.1 VR262 Monochrome Monitor Specifications

#### Dimensions

Height	$39.4~\mathrm{cm}~(15.5~\mathrm{in})$ including feet
Width	45.5 cm (17.9 in)
Depth	39.5 cm (15.4 in)
Weight	18 kg (40 lbs)

#### Horizontal Rate Timing (nominal)

Frequency	54.054 kHz
Front porch	160 ns
Sync pulse	1850 ns
Back porch	1690 ns
Blanking interval	3.70 µs (maximum)
Active video time	14.8 µs
Horizontal period	18.5 µs
Pixels displayed	1024

Optional System Monitors 3-13

#### Vertical Rate Timing (nominal)

	Frequency	60 Hz
	Front porch	0 horizontal lines
	Sync pulse	3 horizontal lines
	Blanking interval	37 horizontal lines
	Active video time	16.0 ms
	Vertical period	16.67 ms
	Lines displayed	864
Power		
	Power supply type	Transistor, switch type ac to dc converter
	AC input	Switch-selectable
	100 V to 120 V nominal	Single-phase, 3-wire 88 V to 132 V RMS, 47 Hz to 63 Hz line frequency
	220 V to 240 V nominal	Single-phase, 3-wire 185 V to 264 V RMS, 47 Hz to 63 Hz line frequency
	Power consumption	65 W
Environ	ment	
	Temperature	$10^\circ$ C to $40^\circ$ C (50° F to 104° F)
	Humidity	10% to 90% maximum wet bulb of 28° C minimum dew point of 2° C

3-14 Optional System Monitors

# 3.4 VR299 Color Monitor

The VR299 is a 500 mm (20 in; 19 in viewable) color monitor for use on Digital workstation products.

The monitor features are:

- In-line gun with Dynamic Astigmatism and Focus (DAF) correction
- 90 degree color CRT (P22 phosphor)
- 1024 pixel x 864 line resolution
- 60 Hz refresh
- 54.0 kHz horizontal frequency
- 0.31 mm dot pitch
- Automatic degauss on power-up
- Integral tilt and swivel
- High efficiency anti-glare bonded panel

### 3.4.1 VR299 Color Monitor Specifications

#### Physical

	Height	18.5 in (47.0 cm)
	Width	19.9 in (50.6 cm)
	Depth	20.7 in (52.7 cm)
	Weight	67.0 lbs (30.0 kg)
Timing		
	Vertical rate	60 Hz
	Horizontal rate	54 Hz
Power		
	AC input	DA model, 100 - 120 Vac 50/60 Hz D3, D4 models, 200 - 240 Vac 50/60 Hz
	Power consumption	150 W
Environ	ment	
	Operating Temperature range	10° C to 40° C (50° F to 104° F)
	Humidity range	10% to 95% non-condensing

Optional System Monitors 3-15

# 3.5 VRT16 Color Monitor

The VRT16 is a 406 mm (16 in), highly integrated color display monitor that is designed for displaying high-resolution graphics. The monitor features include:

- A silica coating on the screen that provides a glare-free display
- High-resolution with 1280 (horizontal) x 1024 (vertical) elements per frame, which allows for high-density color display
- Use of the 66.5 Hz non-interlace method to reduce flicker
- A display that can be turned plus or minus 45 degrees to the right or left, and can be tilted 15 degrees up or 5 degrees down
- A cylindrical screen that reduces distortion when viewed from the sides, sharpens the picture corners, and diminishes reflections

#### 3.5.1 VRT16 Color Monitor Specifications

#### Physical

409 mm (16 in)
406 mm (16 in)
453 mm (17 in)
23.0 kg (50 lbs, 11 oz)

#### **Power Requirements**

AC input	100 - 120 Vac 60 Hz 220 - 240 Vac 50 Hz
Current	100 - 120 Vac 3.7 A max 200 - 240 Vac 2.0 A max

#### Environmental

Operating temperature	10° C to 40° C (50° F to 104° F)
Nonoperating temperature	0° to 60°
Operating humidity	10% - 80%
Nonoperating humidity	5% - 90%

For additional information about the VRT16 monitor, refer to the VRT16 Service Manual (PN ER-VRT16-SM).

3-16 Optional System Monitors

# 3.6 VRT19 Color Monitor

The VRT19 color monitor has a 474 mm (19 in) (diagonal), direct-viewed, anti-reflective coated screen with contrast enhancement. The monitor has a built-in tilt swivel assembly, allowing you to adjust the screen for viewing comfort.

The VRT19 color monitor is a highly integrated color display monitor that is designed for displaying high-resolution graphics.

The VRT19 color monitor features are the same as those of the VRT16 color monitor (refer to Section 3.5.)

#### 3.6.1 VRT19 Color Monitor Specifications

#### Physical

	Height	474 mm (18.66 in)
	Width	480 mm (18.9 in)
	Depth	505 mm (19.9 in)
	Weight	32.5 kg (71 lbs, 11 oz)
Power R	lequirements	
	AC input	100 - 120 Vac 60 Hz 220 - 240 Vac 50 Hz
	Current	100 - 120 Vac 3.7 A max 200 - 240 Vac 2.0 A max
Environ	mental	
	Operating temperature	10° C to 40° C (50° F to 104° F)
	Nonoperating temperature	0° C to 60° C (32° F to 140° F)
	Operating humidity	10% - 80%
	Nonoperating humidity	5% - 90%

This chapter describes the optional printers that can be connected to the VAXstation 4000 Model 60 system. The printers are:

Section 4.1	LA75 Companion Printer
Section 4.2	LA210 Letterprinter
Section 4.3	LN03 Laser Printer

4-2 Optional System Printers

# 4.1 LA75 Companion Printer

The LA75 Companion Printer (Figure 4-1) is a versatile high-speed dot matrix printer that can print in five modes.

- Draft
- Memo
- Near-Letter quality
- Letter quality
- Bit-Map graphics

The LA75 Companion Printer has bidirectional printing and prints at a speed of 250 characters per second. The printer is available in both serial and parallel interface models.



Figure 4–1 LA75 Companion Printer

4-4 Optional System Printers

#### 4.1.1 LA75 Companion Printer Configuration

The LA75 Companion Printer must be configured to ensure that the printer and the system communicate with each other correctly. You may need to change some of the printer's features and values depending on the hardware and software requirements for the system. Check the system's documentation to determine the requirements for baud rate, data bits and parity, and protocol. Table 4–1 lists the factory set configurations for the LA75 Companion Printer. For additional information, refer to *Installing and Using the LA75 Companion Printer* (PN EK-0LA75-UG).

LA75-S Code Version 1.0	
Feature	Values
Baud rate	7 4800
Data bits and parity	7 8-None
Protocol	1 DEC
Form length	2 11 inches
Character set (Digital)	1 U.S. ASCII
Supplemental character set (Digital)	1 DEC Supplemental
Print density (Digital)	1 Draft
Printer ID (Digital)	1 LA50 ID
Text mode right margin (Digital)	1 Truncate
Auto LF on CR (Digital)	2 NO Auto LF
Auto CR on LF (Digital)	2 NO Auto CR
CAN Control code (Digital)	1 Cancel control functions
80 or 132 Columns (Digital)	1 80 Columns
Paper out bell (Emulation)	2 ON
Slashed zero (emulation)	2 Zero without slash
Auto LF on CR (emulation)	2 NO Auto LF
Active character set (emulation)	1 Graphics set A
Auto CR on LF (emulation)	2 NO Auto CR
Power-Up density (emulation)	1 Draft
LQ or NLQ (emulation)	1 Select NLQ

Table 4–1 LA75 Factory Set Configurations

## 4.1.2 LA75 Companion Printer Specifications

The LA75 Companion Printer specifications are listed in the following tables.

#### **Power Requirements**

Voltage/Frequency:

LA75-A2 LA75-A3 LA75-A4 LA75-A5	120 Vac, 50/60 Hz 240 Vac, 50/60 Hz 220 Vac, 50/60 Hz 100 Vac, 50/60 Hz
Power cord	2.0 m (6.7 ft), detachable
Power receptacle	Non-switched, 3-prong, grounded
Power consumption	120 W maximum

#### **Operating Environment**

Temperature range	10° C to 40° C (50° F to 104° F)
Relative humidity	10% to 90%

#### **Physical Characteristics**

Height	12.1 cm (4.8 in)
Width	42.7 cm (16.8 in)
Depth	34.5 cm (13.6 in)
Weight	9.5 kg (21.0 lb)

4-6 Optional System Printers

# 4.2 LA210 Letterprinter

The LA210 Letterprinter (Figure 4–2) is a dot-matrix, receive only (RO) printer. The printer operates in text or graphics mode. Letter quality or draft quality printing can be selected in text mode. In graphics mode, the system controls the dot printing elements.

Letter quality mode provides medium or high density printing at low speed (40 characters per second, maximum). Draft mode provides low density printing at high speed (240 characters per second, maximum).

The LA210 Letterprinter contains the courier 10 U.S. ASCII, courier 10 multinational, and VT100 line drawing character sets. Up to two fonts can be plugged into the printer's font assembly.





MA-0078-84

The LA210 Letterprinter has a standard RS232C serial interface. Figure 4–3 shows the location of the serial interface connector. Figure 4–4 shows the location of the optional parallel interface switches.

Figure 4–3 RS232C Serial Interface Connector



MA-0093-84



Figure 4–4 Parallel Interface Switches (Optional)



#### 4.2.1 LA210 Letterprinter Configuration

The LA210 Letterprinter configuration switches are factory set for use with most Digital systems. Check the system requirements to see if any changes are necessary. If you set the configuration switches, do not change the settings unless there is a change to the communication system. Figure 4–5 shows the location of the configuration switches. For additional information, refer to the *LA210 Letterprinter User Guide* (PN EK-LA210-UG).

CAUTION

Never use a lead pencil to change the switch positions. Use a ballpoint pen or similar item.



Figure 4–5 LA210 Letterprinter Configuration Switches



# 4.2.2 LA210 Letterprinter Specifications

The LA210 Letterprinter specifications are listed in the next tables.

#### **Power Requirements**

Voltage	120 Vac nominal (90 to 128 Vac) 240 Vac nominal (180 to 256 Vac), switch-selectable
Frequency	47 to 63 Hz
Power receptacle	Non-switched, 3-prong, grounded
Power consumption	154 W maximum

#### **Operating Environment**

Temperature range	$10^\circ$ C to $40^\circ$ C (50° F to 104° F)
Relative humidity	10% to 90%

#### **Physical Characteristics**

Height	12.7 cm (5.0 in) without tractor 22.8 cm (9.0 in) with tractor
Width	54.6 cm (21.5 in)
Depth	34.3 cm (13.5 in)
Weight	12.15 kg (27.0 lb)

4-12 Optional System Printers

# 4.3 LN03 Laser Printer

The LN03 Laser Printer is a nonimpact printer that uses a laser diode and an electrophotographic printing process. The LN03 Laser Printer prints at a rate of eight pages per minute (text only) with print quality at 300 by 300 dots per inch.

The LN03 Laser Printer (Figure 4–6) has an RS232 serial interface that allows connection to systems for text printing, and graphics by way of the sixel standard protocol.





#### 4.3.1 LN03 Laser Printer Configuration

The LN03 Laser Printer has two 6-position configuration switchpacks, located at the rear of the printer. The switchpacks are used to configure the printer operating requirements. Figure 4–7 shows the location of the switchpacks and the printer configuration factory settings. If necessary, change these settings to match the communication parameters of the system.

NOTE

Turn off power to the printer before resetting the configuration switches. The new switch settings are invoked when you turn the power on again.

#### CAUTION

Never use a lead pencil to change the switch positions. Use a ballpoint pen or similar item to change the switch settings.

The switchpacks are marked 1 (ON) and 0 (OFF). For additional information, refer to the *LN03 Technical Manual* (PN EK-OLN03-TM).



Figure 4–7 LN03 Laser Printer Configuration Switches



# 4.3.2 LN03 Laser Printer Specifications

The LN03 Laser Printer specifications are listed next.

#### **Power Requirements**

Voltage	120 Vac (85 to 132 Vac) 240 Vac (187 to 264 Vac)
Frequency	50/60 Hz
Power cord	3.0 m (10.0 ft) detachable
Power requirement	1 kVA maximum
Power consumption	120 Vac, 950 W maximum 240 Vac, 850 W maximum
Heat dissipation	120 Vac, 3240 Btu/h 240 Vac, 2900 Btu/h

#### **Operating Environment**

Temperature range	10° C to 32° C (50° F to 90° F)
Relative humidity	20% to 80%

#### **Physical Characteristics**

Height	38.1  cm (15.0  in, with exit tray)
Width	53.4 cm (21.0 in)
Depth	59.7 cm (23.0 in, with tray)
Weight	35 kg (77.0 lb)

# Index

### D

DSW21 synchronous communications adapter, 2–5
cables, 2–7
environmental specifications, 2–8
installation, 2–7
specifications, 2–9

# L

LA210 Letterprinter, 4–6 configuration, 4–9 specifications, 4–11 LA75 printer, 4–2 configuration, 4–4 specifications, 4–5 LN03 laser printer, 4–12 configuration, 4–13 specifications, 4–15

# Μ

Model 60 System memory configuration, 2–2 MS44 memory module, 2–2 configuration, 2–2 specifications, 2–4

# R

RRD42 CDROM disc drive, 1–6 SCSI ID setting, 1–6 specifications, 1–9
RX26 diskette drive, 1–10 SCSI ID setting, 1–10 specifications, 1–12
RZ23L hard disk drive specifications, 1–5 to 1–6 RZ24 hard disk drive specifications, 1–5 to 1–6 RZ2x hard disk drives, 1–2 SCSI ID setting, 1–2

# Т

TZK10 (QIC) tape drive, 1–13 SCSI ID setting, 1–13 specifications, 1–16

# V

VR262 monitor, 3-12 specifications, 3-12 to 3-13 VR299 color monitor, 3-14 specifications, 3-14 VR319 monochrome monitor, 3-2 refresh rate, 3-3 specifications, 3-5 video timing, 3-6 VR320 color monitor, 3-7 refresh rate, 3-8 specifications, 3-10 video timing, 3-11 VRT16 color monitor, 3-15 specifications, 3-15 VRT19 color monitor, 3-16 specifications, 3-16